


**MODEL  
600A**

**2011**



**OWNERS MANUAL**  
**(MANUEL D'UTILISATION)**  
**(MANUAL DE UTILIZACIÓN)**

103

## Safe Operation Practices



This symbol points out important safety instructions which, if not followed, could endanger the personal safety and/or property of yourself and others. Read and follow all instructions in this manual before attempting to operate your vacuum machine. Failure to comply with these instructions may result in personal injury.

### General Operation

- Read, understand, and follow all instructions in the manual and on the machine before starting. Keep this manual in a safe place for further and regular reference and for ordering replacement parts.
- Only allow responsible individuals familiar with the instructions to operate the machine. Be sure to know controls and how to stop the machine quickly.
- Never put your hands near moving parts.
- Only allow qualified individuals for the maintenance of your machine.
- Remove all obstacles, which may interfere with the machine functions.
- Clear the work area such as electrical wires, buckets, knives etc.
- Be sure that everyone else is clear of your work area before operating the machine.
- Do not sit nor stand on the machine.
- Always turn off the machine after your work is done. Never leave a running machine unattended.
- Always disconnect and wait till the machine has cooled before attempting any maintenance.
- Do not wear loose fitting clothes or jewelry as they may get caught in moving parts of the machine.
- Always wear security shoes, to prevent injury caused by moving the machine or objects falling from the machine.
- Never exceed the time limit to seal, which is recommended by the manufacturer. This is to avoid any damage that may be caused to the sealing bars and to eliminate the risk of fire in the machine. Thus avoiding corporal burns.
- Never touch the sealing bars after they have been used, this will avoid corporal burns. Wait a few minutes to let the machine cool down before touching.
- Always make sure that the sealing bars are well installed in their "Guide Blocks" before starting a cycle.
- Never incline the machine more than 30 degrees, it may tip over and hurt someone seriously.
- Work only in daylight or good artificial light.

**Do not operate the machine while under the influence of alcohol or drugs!**

## Service

- Use proper containers when draining the oil. Do not use food or beverage containers that may mislead someone into drinking from them. Properly dispose of the containers, or store in a safe place immediately following the draining of the oil.
- Prior to disposal, determine the proper method to dispose of waste from your local office of Environmental Protection Agency. Recycling centers are established to properly dispose of materials in an environmentally safe fashion.

**Do not pour oil or other fluids into the ground, down a drain or into a body of water.**

### **Warning-Your responsibility:**

This machine should only be operated by personal who can read, understand and respect warnings and instruction regarding this machine in the owners manual.

# VACUUM PACKAGING MACHINE

## MODEL 600A

### GENERAL TABLE OF CONTENTS

#### I OPERATION INSTRUCTIONS

#### II MECHANICAL

- A- Front view general assembly drawing
- B- Rear view general assembly drawing
- C- Cover adjustment procedure
- D- Central shaft assembly drawing
- E- Seal bar assembly drawings  
(twin seal)
- F- Seal bar assembly drawings  
(electrical bag cut option)
- G- Seal bar assembly drawings  
(top and bottom sealing option)
- H- Gas injection kit installation drawing  
(gas injection option)

#### III ELECTRICAL

- A- Electrical drawing low voltage
- B- Electrical drawing high voltage 1 phase
- C- Electrical drawing high voltage 3 phase
- D- Electrical drawing high voltage 1 phase 50 Hz
- E- Electrical drawing high voltage 3 phase 50 Hz

#### IV PNEUMATIC

- A- Pneumatic drawing

# VACUUM PACKAGING MACHINES

## OPERATION INSTRUCTIONS

### TABLE OF CONTENTS

1. Setting up the machine
2. Electrical connection
3. Operation
  - 3.1 Working principles
  - 3.2 Special packaging
    - 3.2.1 Gas flushing
    - 3.2.2 Top and bottom sealing (bi-active sealing)
    - 3.2.3 Electrical bag cut
  - 3.3 Setting of digital controls
  - 3.4 Daily cleaning
4. Trouble shooting
  - 4.1 Failure during a packaging cycle
  - 4.2 Insufficient vacuum
    - 4.2.1 Leakage in the bag
    - 4.2.2 No leakage in the bag
    - 4.2.3 Insufficient vacuum in the chamber
  - 4.3 Faulty seal
    - 4.3.1 Insufficient seal
    - 4.3.2 No seal
    - 4.3.3 Permanent sealing current
    - 4.3.4 Seal does not stick
  - 4.4 Fault in the valves
  - 4.5 Control board failure
5. Regular maintenance

# SIPROMAC INC.

## VACUUM PACKAGING MACHINES

### 1. SETTING UP THE MACHINE:

Before choosing the site for the machine, please consider that you will also need room for packaged and non-packaged products apart from the space needed for the machine itself.

Keep in mind that the machine must not be set up upon uneven ground. Especially with mobile models, the weight of the pump might then cause warping of the machine. Then the lid will not fit correctly.

Before starting to work, check the oil view glass on the pump, if there is a sufficient quantity of oil in the pump. Never use oil other than recommended by the producer. Never exceed maximum quantity of oil indicated, when adding or changing oil. Verify weekly.

Due to the oil viscosity, the machine is hard to start when temperatures are very low. Therefore the pump should be put in a room with an air temperature of at least 50°F (+10°C). On the other hand, there must be free access of air to the pump to allow for cooling so that operation temperature of 160°F (70°C) is not exceeded.

### 2. ELECTRICAL CONNECTION:

Electrical connections must be made by qualified personnel. This person must make sure that the electrical entries corresponds to the proper voltage and amperage of the machine.

All vacuum machines are supplied with an electrical schematic drawing.

An important step in connecting the machine is to make sure that the pump turns in its correct rotation.

**Warning: The pump should not rotate more than 3 to 4 seconds in the wrong rotation or it may cause serious damage. The proper rotation is indicated by an arrow on the pump motor.**


### 3. OPERATION:

#### 3.1 Working principles:

A vacuum packaging cycle is made of 3 stages. First the vacuum is made, the air is completely taken out of the chamber and from bag containing the product. (See figure 1). Then it is possible to inject neutral gas from the nozzles, if the product is delicate. Finally, a mechanism pushes the sealing bar to the rubber support to seal the bag.

To obtain nice packages, the products and the bags have to be of proportional sizes. The bag's opening should never exceed 50 cm(2") past the seal bars. The product should be centered in height in relation to the seal bar by adjusting the spacers provided.

To obtain a good seal, make sure that no residue of fat is left between the bag's inner sides where sealing is done.



## 3.2

### Special packaging:

#### 3.2.1 Gas flushing (option):

There is an atmospheric pressure of 1 kg/ sq. cm(14 lbs/sq. inch ) upon products when fully evacuated. Products which can be damaged by high pressure must be packaged with a partial vacuum, or the pressure must be counterbalanced by inflating the bag with gas (nitrogen or carbon dioxide) before sealing after evacuation.

For gas flushing, the bags are placed on the sealing bars, the open end placed over the gas nozzles mounted alongside the sealing bar. After evacuation, the vacuum valve closes and the gas valve opens. Gas level (%) can be set in the program menu.

The necessary gas tank and pressure valve mounted on tank is not supplied by Sipromac. The pressure of the gas regulator should be set at approximately 1/3 kg/sq. cm(5 lbs/sq. inch.). Each machine has an adaptor for gas connection when gas flush option is ordered.

#### 3.2.2 Top and bottom sealing (optional):

When sealing aluminium laminate bags (especially bags for e.g. coffee) it is imperative to have an upper and a lower sealing bar.

#### 3.2.3 Electrical bag cut (optional):

This option is used to obtain a package that the excess bagtail is cut off close to the seal (cannot be used with top and bottom sealing).



### 3.3 Vacuum packaging operation:

Note: Refer to the menus structure on page 8 and the keyboard detail on page 9.

#### 3.3.1 Basics:

Use key "POWER" to power ON / OFF the vacuum packaging machine. When the unit is energized, the identification of the last executed program is displayed on LCD screen.

Use the "ESC" key to change over from the programs menu to the functions menu and from the functions menu to the programs menu.

In functions menu, use key "SELECT" to select a function and key "ENTER" to accede and executed the selection.

In programs menu, use key "SELECT" to select a program and key "ENTER" to accede and modify the selection.

In programs submenu, use key "ENTER" to pass over the parameters and point to the following one; the parameters are blinking to point out the acquisition mode. A return to programs menu is performed automatically following the last parameter acquisition.

In program submenu, use key "ESC" to get back to the programs menu. Strike any key to clear the error messages which may be displayed on LCD screen.

#### 3.3.2 Functions menu:

##### 3.3.2.1 Create a program:

When executing the "create a program" function, the program submenu is acceded, starting with the identification. The initial identification "Pxx NO NAME" is given to the program and all parameters are established to zero; the program number is allocated automatically.

##### 3.3.2.2 Delete a program:

When executing the "delete a program" function, the programs menu is acceded and the number of the first program in memory is blinking to point out the deletion mode. Use key "SELECT" to select a program and key "ENTER" to accede and confirm deletion of the selection. Use key "ESC" to unconfirm a deletion and to leave the function. When leaving the function, the number of the actual program on LCD screen cease to blink.

##### 3.3.2.3 Select operating mode:

When executing the "select operating mode" function, which is available only for the automatic units, the actual selection is blinking to point out the acquisition mode. Use key "SELECT" to get through the operating modes, which are automatic, semi-automatic and manual; the validation of the selected operating mode is performed automatically. Use key "ESC" or "ENTER" to leave the function and get back to the program menu.

### 3.3.3 Programs menu:

#### 3.3.3.1 Program identification:

For a selected program, set the identification, using the numeric keyboard characters chart; press numeric key until the desired character is selected (4 times for the numeric value). Use key "ENTER" to validate the character and to validate the characters string at the end (the new characters string is blinking). In a middle of an acquisition, use key "ESC" to come backward and erase one or several characters.

Example: EXAMPLE 1 → keys 2, 2, ENTER → E  
(9 characters) keys 8, 8, 8, ENTER → X  
keys 1, ENTER → A  
keys 5, ENTER → M  
keys 6, ENTER → P  
keys 4, 4, 4, ENTER → L  
keys 2, 2, ENTER → E  
keys 9, 9, 9, ENTER → space  
keys 1, 1, 1, 1, ENTER → 1  
key ENTER to validate the characters string

#### 3.3.3.2 Vacuum level setting:

For a selected program set the vacuum level, starting with the values; the decimal point is automatically inserted following the second digit entry and the validation is automatically performed following the third digit entry (the new vacuum level is blinking). The vacuum level is rounded off to the nearest half value. In the middle of an acquisition, use key "ENTER" to validate the vacuum level and key "ESC" to come backward and start over with a new acquisition (the old vacuum level is blinking). Set vacuum level to zero to bypass the pressure transducer and proceed only using the vacuum plus time.

Examples: 90.0% → keys 9, 0, 0 or 9, 0, ENTER or  
keys 9, 0, 1 or 9, 0, 2 or 9, 0, 3 or 9, 0, 4  
97.5% → keys 9, 7, 5 or  
keys 9, 7, 6 or 9, 0, 7 or 9, 0, 8 or 9, 0, 9  
0.0% → keys 0, 0, 0 or 0, ENTER

#### 3.3.3.3 Vacuum plus time setting:

For a selected program set the vacuum plus time, in seconds; the validation is automatically performed following the second digit entry (the new vacuum plus time is blinking). In a middle of an acquisition, use key "ENTER" to validate the vacuum plus time and key "ESC" to come backward and start over with a new acquisition (the old vacuum plus time is blinking).

Examples: 1s → keys 0, 1 or 1, ENTER  
15s → keys 1, 5

#### 3.3.3.4 Gas flush level setting:

For a selected program set the gas flush level following the same procedure as for the vacuum level; the maximum gas flush level setting is 10% below the vacuum setting.

#### 3.3.3.5 Sealing time setting:

For a selected program set the sealing time, starting with the seconds; the decimal point is automatically inserted following the first digit entry and the validation is automatically performed following the third digit entry (the new sealing time is blinking). The sealing time is truncated to the nearest half hundredth. In a middle of an acquisition, use key "ENTER" to validate the sealing time and key "ESC" to come backward and start over with a new acquisition (the old sealing time is blinking).

Examples:

- 4.50s → keys 4, 5, 0 or 4, 5, ENTER or  
keys 4, 5, 1 or 4, 5, 2 or 4, 5, 3 or 4, 5, 4
- 2.35s → keys 2, 3, 5 or  
keys 2, 3, 6 or 2, 3, 7 or 2, 3, 8 or 2, 3, 9
- 0.00s → keys 0, 0, 0 or 0, ENTER

#### 3.3.4 Vacuum cycle execution:

For the manual units and the automatic units set on manual, close the cover to initiate a vacuum cycle. For the automatic units set on semi-automatic or on automatic, use push button "STOP / START" to initiate or interrupt a vacuum cycle. A selected program can be initiated only in the programs menu, when no modifications are in progress, and the access to the other programs and functions is denied. During cycle execution the operation status is sequentially displayed on LCD screen, except for the parameters established to zero, which are not displayed:

- chamber vacuum level during vacuum sequence,
- vacuum plus time status during vacuum plus sequence,
- chamber vacuum level during gas flush sequence,
- sealing time status during sealing sequence,
- chamber vacuum level during atmosphere sequence.

During cycle execution, use key "1" to abort the vacuum sequence and execute the following sequence, which is gas flush or sealing, and key "ENTER" to accede and modify the program; the parameters become valid only for the following vacuum cycles.

#### 3.3.5 System monitor:

To accede the diagnostics menu, power up the vacuum packaging machine while keeping pushed in the "ESC"key. Use key "SELECT" to select the system monitor function and key "ENTER" to accede and visualize the monitored parameters. Use key "SELECT" to change over from the software revision, the amount of working hours done and the amount of complete cycles performed since first initialization.

## -MENUS STRUCTURE-

- Functions menu:

"F1 CREATE A PRGM"  
"F2 DELETE A PRGM"  
"F3 SELECT OPMODE" (automatic units only)

- Programs menu:

"Pxx NAME"

Program submenu:

"VACUUM: xx.x%"	(10.0% - 99.5%)
"VACUUM PLUS: xxs"	(0s - 99s)
(units with gas option) "GAS FLUSH: xx.x%"	(0.0% - 10% below the vacuum level)
"SEAL TIME: x.xxs"	(0.00s - maximum unit allocated setting)
"Pxx NAME"	(12 characters)

- Diagnostics menu (keys "ESC" & "POWER" for access):

"DIAGNOSTICS MENU" (access code required)

"D1 INPUTS TEST"

"D2 OUTPUTS TEST"

"D3 MODEL SELECT"

"D4 GAS OPTION"

"D5 SEALING TIME"

"D6 COOLING TIME"

"D7 LOADING TIME" (automatic units only)

"D8 UNLOADNG TIME" (automatic units only)


"SYSTEM MONITOR" (no access code required)

"SOFTWARE: R x.xx"

"WORK HRS: xxxxx"

"CYCLES: xxxxxxxx"

-KEYBOARD DETAILS-



**WARNING: ALL ELECTRICAL WORK DESCRIBED IN THIS BROCHURE SHOULD BE DONE BY A QUALIFIED AND AUTHORIZED TECHNICIAN.**

### 3.4 Daily cleaning:

For hygienic cleanliness, it is imperative to clean chamber and spacers daily. Also clean the lid rubber to assure tight seat of the lid.

## 4. TROUBLE SHOOTING:

### 4.1 Failure during packaging cycle:

#### 4.1.1 "VACUUM ERROR" message is displayed on LCD:

No pressure variation is picked up by the PCB transducer during the vacuum sequence within a preset period of time.

- Check vacuum lines for potential leaks or kinks.

#### 4.1.2 "GAS FLUSH ERROR" message is displayed on LCD:

No pressure variation is picked up by the PCB transducer during the gas flush sequence within a preset period of time.

- Check gas flush and vacuum lines for potential leaks or kinks.

#### 4.1.3 "ATMOSPHERE ERROR" message is displayed on LCD:

No pressure variation is picked up by the PCB transducer during the atmosphere sequence within a preset period of time.

- Check vacuum lines for potential leaks or kinks.

#### 4.1.4 "COVER DOWN ERROR" message is displayed on LCD(manual units):

The input signal of the down position switch has been lost during cycle execution.

- Check limit switch adjustment.

## 4.2 Insufficient vacuum:

### 4.2.1 Leakage in the bag:

Most frequently, insufficient vacuum in bags is due to leakage in bag and not due to any fault of the machine.

Pin-hole leak for which there is no obvious explanation is due to faulty bag material.

Pin-hole leak caused by sharp edge of the product (bone, etc.). Use bone-guard or thicker film.

Tear in bag by careless handling (sharp edge on filling table, damage made by retailer or customer).

Leakage in lateral or bottom seal, complain to supplier of bags or film.

### 4.2.2 No leakage in the bag:

Bag is too large, therefore the surplus of air remains visible (there is surplus of air in 0.4% of the bag volume in each bag). Use bags of suitable size.

Evacuation time is too short:

Pressure bar is jammed and closes opening of bag during evacuation.

### 4.2.3 Insufficient vacuum in chamber:

If troubles described under 4.2.1 and 4.2.2 do not apply, there is something wrong with the evacuation. To find the leakage quickly, check for leaks with a precision vacuumeter, going back step by step from the chamber to the pump.

At the chamber (measuring point at base of valve) at maximum time of evacuation. If more than 6 torr, proceed directly to the pump, if more than 3 torr: have pump service by pump supplier. If pressure at pump is good, reconnect hoses to pump and measure again.

Verify at vacuum hose connections and valve connections.

When proceeding this way, starting from pump, loss of pressure per step must not exceed 0.5 to 1 torr.

Warning: Verify connections of measuring equipment before verifying machine.

Most frequent points of leakage: lid gasket, damaged vacuum hose or loose hose clamps.

#### 4.3 Faulty seal:

##### 4.3.1 Insufficient seal:

Damaged teflon or silicone rubber.

Sealing pressure too low, bellows leaking or pressure bar jammed.

Leakers in seal: heating wire mechanically damaged (knicked) or silicone rubber uneven.

##### 4.3.2 No seal:

Sealing wire burnt.

Faulty contact in sealing circuit.

Sealing transformer burnt through.

Contactors does not work.

##### 4.3.3 Permanent sealing current:

Contactors is jammed check sealing transformer for damage through overload.

##### 4.3.4 Seal does not stick:

Insufficient layer of polyethylene (inferior quality of bags).

Seal area extremely contaminated by fat or meat juice. Use filling aid.

Sealing temperature is too low (when using very thick films).

Warning: Do not increase sealing time more than really necessary; higher temperature will reduce working life of teflon and silicone rubber.

#### 4.4 Fault in the valve:

Vacuum or air valve does not open.

Check whether there is voltage on the magnetic valves during their period of operation. If there is no voltage a wire is broken or the PC board is damaged.

Lid does not open at the end of the cycle; air enters, but there is still 20 - 40% vacuum in chamber. Vacuum valve does not close.



#### 4.5 MC40 Control board failure

NOTE: Refer to menu structure on page 8.

This board software is allowing access to a "Diagnostics Menu". Only qualified service technicians are authorized to access this menu by entering a security password.

By acceding either the "D1 input test" feature or the "D2 output test" feature, a trained technician will be able to quickly know the origin of the problem: pump, sealing system, pneumatic problem, security switches problem, etc...

Keep in mind that in most cases trouble is due to a leakage, loose electrical connection or evident damage to the main component: vacuum pump, valves..., electrical contactors, thermal overload, fuses holder or transformer.

For assistance do not hesitate to contact your local service technicians.

#### 5. Regular maintenance:

Routine controls to be made at regular intervals:

Check teflon for wear.

Check silicone rubber for burnt spots and smooth even position.

Check pressure bar for jamming.

Check lid sealing for damage and hardened spots.

Check switch-point of micro switch, adjust if necessary.

Check evacuation hose for damage (contraction of diameter, or abrasions).

Check vacuum connections for tightness.

Check oil in pump (oil level in view glass; add if necessary. Regular change of oil - necessity indicated by change of color).

Check vacuum in chamber with precision vacuumeter.


Check function of cycle with various settings of timers.

#### INSTALLATION NOTICE FOR MODELS: 420A, 450T, 450A, 550A, 600A, 620A, 650A AND 700A


#### IN ORDER TO RESPECT NSF REGULATIONS:

**NOTE: A PLASTIC CAP IS INSTALLED ON THE TABLE TOP VACUUM INLET USED FOR LEANING PURPOSES ONLY AND IS TO BE REMOVED PRIOR TO OPERATING THE MACHINE.**






# MECHANICAL DRAWING




**NOTE:** - FOR GAS INJECTION KIT INSTALLATION SEE DRAWING #010-0017

ITEM	PART #	DESCRIPTION	QTY.
1	005A0457	STRUCTURE ASSEMBLY	1
2	005-0150	TABLE ASSEMBLY	1
3	005-0453	8" COVER ASSEMBLY	1
4	005-0454	12" COVER ASSEMBLY (OPT.)	1
5	005A0583	P.C. BOARD SUPPORT ASSY	1
6	051-0740	FLAT WASHER 1/4" S/S	4
7	051-0591	ACORN NUT 1/4"-20 NC. S/S	4
8	051-0740	FLAT WASHER 1/4" S/S	4
9	051-0250	HEX. BOLT 1/4"-20 NC. X 1 1/2" S/S	32
10	051-0581	HEX. NUT 1/4"-20 NC. NYLON LOCK S/S	16
11	002-0326	LEFT/ SEAL BAR GUIDE BLOCK	4
12	002-0327	RIGHT/ SEAL BAR GUIDE BLOCK	4
13	051-0780	FLAT WASHER 3/8" S/S	4
14	051-0620	HEX. NUT 3/8"-16 NC. S/S	4
15	005-0320	BELLOWS ASSEMBLY	4
16	005A0568	SEAL BAR ASSY W/ SUPPORT	4
17	005A0569	SEAL BAR ASSY W/ SUPPORT (BAG CUT OPT.)	4
18	005A0570	SEAL BAR ASSY W/ SUPPORT (TOP & BOT OPT.)	4
19	005A0810	GAS 3 INJECTION BAR ASSY (OPT.)	2
20	005-0571	GAS 3 INJECTION BAR ASSY (OPT.)	2
21	005A0811	REAR GAS 4 INJECTION BAR ASSY (OPT.)	2
22	005A0446	FRONT GAS 4 INJECTION BAR ASSY (OPT.)	2
23	008-0464	GAS INJECTION CONNECTION TUBE	4
24	005-0322	FILLER PLATE ASSEMBLY	4
25	057-0089	1/4" x 5/8" O.D. EPDM RUB. SEAL WASHER	4



--DETAIL--




MACHINE: 600A  
 PART: MACHINE ASSEMBLY FRONT VIEW  
 ITEM: M.A.L. LEBLANC  
 DATE: 05-09-07  
 INC. ST-GERMAIN DE GRANTHAM QUEBEC CANADA  
 N.T.S.  
 M-1 QTY: 1  
 005A0324

J	REDRAWN	MODIFICATION	DATE	M.A.L.	INT.
E.L.					

1005-0325

ITEM	#PART	DESCRIPTION	QT.
1	005-0324	MACHINE ASSEMBLY FRONT VIEW	1
2	005-0317	GUIDE ARM SHAFT ASSEMBLY	1
3	051-0783	FLAT WASHER (THICK) 3/8" S/S	20
4	051-0360	HEX. BOLT 3/8"-16 NC. X 1" S/S	8
5	051-0820	HEX. NUT 3/8"-16 NC. S/S	8
6	004-0280	COVER ARM ASSY	2
7	056-0167	KEY 1/4" SQ X 1" W/ ROUNDED END	2
8	001-1876	LOWER WIRE SUPPORT (TOP & BOT OPT.)	1
9	051-0422	HEX. BOLT 3/8"-16NC. X 3 1/4" S/S	2
10	051-0622	HEX. NUT 3/8"-16 NC. NYLON LOCK S/S	2
11	057-0013	CENTRAL SHAFT END CAP	2
12	002-0390	SET SCREW COLLAR	2
13	051-0178	SET SCREW 1/4"-20 X 5/16" S/S	4
14	004A1394	GUIDE ARM PRE-ASSEMBLY	1
15	058-0050	SPACERS	2
16	058-0060	SPACERS	2
17	056-0331	EXT. RETAINING RING 1/2" S/S	2
18	005-0374	ELECTRICAL BOX PRE-ASSEMBLY	1
19	001-1364	LEFT/ ELECTRICAL BOX UPPER SUPPORT	1
20	051-0180	HEX. BOLT 1/4"-20 NC. X 1/2" S/S	3
21	051-0740	FLAT WASHER 1/4" S/S	13
22	051-0581	HEX. NUT 1/4"-20 NC. NYLON LOCK S/S	3
23	052-0402	HEX. BOLT 1/4"-20 X 1/2" BRASS	4
24	051-0190	HEX. BOLT 1/4"-20 NC. X 3/4" S/S	2
25	004-0279	ELECTRICAL BOX COVER PRE-ASSY	1
26	114-2020	DRYER FILTER	1
27	101-0210	STRAIGHT 1/4" FNPT X 1/4" HOSE	1
28	101-0200	STRAIGHT 1/4" MNPT X 1/4" HOSE	1
29	001-2062	DRYER SUPPORT	2
30	005-0323	GAS INLET ASSEMBLY (OPTION)	1
31	051-0180	HEX BOLT 1/4"-20 NC X 1/2" S/S (OPTION)	1
32	051-0740	FLAT WASHER 1/4" S/S (OPTION)	1
33	051-0581	HEX NUT 1/4"-20 NC NYLON LOCK S/S (OPTION)	1
34	130-4PHB	4" PL CASTER SWIVEL W/ BRAKE	2
35	130-4PHD	4" PL CASTER SWIVEL W/ O BRAKE	2
36	052-0520	BOLT 5/16"-18 NC. X 3/4" ZINC	16
37	051-0760	FLAT WASHER 5/16" S/S	32
38	052-3110	NUT 5/16"-18 NC. ZINC	16
39	004A1470	"BUSCH" 63M3 & PLUMBING	1
40	004A1468	"BUSCH" 100M3 & PLUMBING	1
41	004A1469	"BUSCH" 165M3 & PLUMBING	1
42	004A1471	"BUSCH" 255M3 & PLUMBING	1
43	056-0130	RIVNUT 1/4"-20 ALUMINIUM (OPTION)	4
44	052-0420	SCREW 1/4"-20 X 3/4" RND SLOT BRASS (OPTION)	4
45	004-0726	REAR PANNEL PRE-ASSY (OPTION)	1



MACHINE	600A	
PART	MACHINE ASSEMBLY REAR VIEW	
ITEM:	QMS	DATE 00-12-14
MAT:	S.L.	DATE 05/20/13
N.T.S.		M-1
ST-GERMAIN DE GRANTHAM QUEBEC CANADA		005-0325

MODIFIED VIEW	ITEM #1	M.A.L.
N	04-12-15	J.G.
M	04-01-14	J.C.
L	03-12-09	Y.C.
K	02-11-05	S.L.
J	00-05-12	S.L.
I	00-02-14	S.L.
H		
G		
F		
E		
D		
C		
B		
A		

MODIFICATION

# **MODEL 600A**

## **COVER ADJUSTMENT PROCEDURE**


Reference Drawing:# 005-0325  
# 004A0122

**PROBLEM:** MACHINE TABLE AND COVER SEEMS TO BE STRAIGHT, LID GASKET IS GOOD BUT COVER DOES NOT SIT PROPERLY ON BOTH SIDES OF TABLE.




1. Floor should be flat (within 1/8" approx.).
  - 2.1 Mark position of original adjustment of lower shaft position & measure guide arm length. (See drawing # 005-0325; items: #14 & #2).
  - 2.2 Loosen the two nuts on the guide arm (See drawing # 005-0325; items #15).
  - 2.3 Now move the cover each side and check how cover sits on the table. Distance between table and lid gasket should be under 1/16" approx. If so, go to step 3.0 for guide arm adjustment. Otherwise go to step 2.4 for central arm adjustment.
  - 2.4 Put chamber in upright position and check with a square angle to see if arms are parallel. If not, loosen bolt at the end of one arm and adjust until square (See drawing # 005-0325; items #6, #9 & #10).
  - 2.5 When closing cover (guide arm still loose), if cover is not sitting properly on either the front or rear of the table, you have to change the height of a central bearing (See drawing # 004-0122; item #3) until cover is sits properly each side (less than 1/16"). Keep in mind that the rear of the cover should touch the table before the front.
3. Adjustment of guide arm: two things have to be adjusted; the length and the lower axis position. Each of these should be adjusted separately. Fix the lower axis in a central position, then adjust guide arm length by marking its position. When chamber is at the left and at the right, Adjustment can be done a couple of times until everything is ok.

**SPRING ADJUSTMENT PRODEUDRE**

- A- PLACE COVER UP(ARM VERTICAL) TO FREE TENSION OF SPRINGS.
- B- LOOSEN BOLTS ITEMS #10 ON THE LEFT & RIGHT SPRING SUPPORT PLATE ASSY ITEM #8.
- C- TURN SPRING/BLOCK ASSEMBLY TO OBTAIN A SPACE APPROX. 8mm (5/16") AS SHOWN BELOW.



E- RETIGHTEN BOLTS ON SPRING SUPPORT PLATE ASSY. (ITEMS #10).



ITEM	PART #	DESCRIPTION	QTY.
1	005-0150	TABLE ASSEMBLY	1
2	002A0318	CENTRAL SHAFT	1
3	075-1650	FLANGED BEARING W/ GREASE FITTING 90°	2
4	051-0441	HEX.BOLT 1/2"-13 x 1 1/2" S.S.	4
5	051-0630	HEX.NUT 1/2"-13 S.S.	4
6	051-0790	FLAT WASHER 1/2" S.S.	4
7	008-0315	CENTRAL SHAFT SPRING	2
8	004A0117	SUPPORT PLATE ASSEMBLY	2
9	002A0319	SPRING BLOCK	2
10	052-0775	HEX.BOLT 3/8"-24 NC x 2 1/2" ZINC	4
11	052-0777	HEX.BOLT 3/8"-24 x 3" ZINC	4
12	052-2060	FLAT WASHER 3/8" ZINC	12
13	052-3128	HEX.NUT 3/8"-24 ZINC	8
14	005-0154	MICRO-SWITCH COLLAR	1
15	051-0334	SET SCREW 3/8"-16 x 3/8" S.S.	2
16	026-0610	MICRO-SWITCH	2
17	001-1294	MICRO-SWITCH FIXATION PLATE	2
18	051-0180	HEX.BOLT 1/4"-20 x 1 1/2" S.S.	2
19	051-0740	FLAT WASHER 1/4" S.S.	4
20	051-0580	HEX.NUT 1/4"-20 S.S.	2
21	052-2071	CONTACT WASHER 3/8" STEEL	4
22	056-0168	KEY 1/4" SQ x 1 1/2" W/ ROUNDED END	2
23	051-0783	WASHER 3/8" FLAT THICK SS	4

600A


CENTRAL SHAFT ASSEMBLY

DATE 09-11-17

DATE 04-12-16

ST-GERMAIN DE GRANTHAM QUEBEC CANADA


004A0122



REV.	DESCRIPTION	DATE	INT.
D	MODIFIED VIEW ITEM #1	01-12-15	M.A.J.
C	REVISED DRAWING	03-17-70	S.L.
B	REDRAWN/ MODIFIED SPRING BLOC	09-11-17	S.L.
A			


005A0583

ITEM	PART #	DESCRIPTION	QTY.
1	004A0425	FRONT MC-40 SUPPORT PRE-ASSY	1
2	051-0092	SCREW #4-40 x 1 1/4" FLAT SLT S/S	4
3	051-0713	WASHER #4 FLAT S/S	4
4	058-0120	CPVC SPACER 0.120" x 1/4" x 5/8"	4
5	051-0540	NUT #4-40 HEX S/S	8
6	051-0715	WASHER #4 LOCK SS	4



033-0015 OR  
033-0017 OR  
033-0018 OR  
KEY BOARD REF.  
(NOT INCLUDED)

USE JIG TO INSTALL, IN REGARDS TO OPENINGS IN ITEM #1



033-0038 P.C. BOARD REF. (NOT INCLUDED)

G  
LET.  
REDRAWN  
MODIFICATION  
05/09/01 M.A.  
DATE INT.

QUANTITE 420A, 450A, 460T, 500A, 550A, 600A, 620A & 650A  
PART  
TEN  
MAT.

FRONT MC-40 SUPPORT ASS'Y

CNC  
DATE 05-09-01  
APP. BY M.A.L.  
DATE 5-10-01

DEPT. M  
QTY. 1

SIPROMAC  
BY-GERMANT DE GRANTIAN  
SUBREC CANADA

N.T.S.


005A0583



1005A0457

ITEM	PART #	DESCRIPTION	QT.
1	004B0114	STRUCTURE PRE-ASSEMBLY	1
2	005A0584	REAR MC-40 SUPPORT ASSY	1
3	051-0287	BOLT 1/4-20 x 3-1/4" S/S	4
4	051-0757	WASHER 1/4" FLAT THICK S/S	4
5	058-0140	PLASTIC SPACER 0.266" x 1/2" x 2 1/4"	4
6	051-0750	WASHER 1/4" LOCK S/S	4
7	051-0580	NUT 1/2"-20nc. S/S	4
8	001A3230	STRUCTURE COVER	1
9	054-0180	METAL SCREW #6 x 3/8" PAN SLOT S/S	8
10	057-5010	NYLON SCREW #10 RECEPTACLE INSERT	8

-UNE FOIS L'ITEM 2 INSTALLÉ, UTILISER DE L'ADHÉSIF MARIN 5200 #169-0210 POUR SCÉLLER LE HAUT, LES CÔTÉS ET LES CORNS DU BAS ILE CÔTÉ DU DESSOUS NEST PAS SCÉLLÉ)  
 -ONCE ITEM 2 IS INSTALLED, USE 169-0210 5200 MARINE ADHESIVE TO SEAL TOP, SIDES & BOTTOM CORNERS UNDER SIDE NOT SEALED!




600A & 620A		SIPROMAC	
STRUCTURE ASSY		ST-GERMAIN DE BRANTHAM	
N.T.S.		QUEBEC CANADA	
DATE: 05-09-07	NO: 05-11-95	DEPT: M	QTY: 1
DATE: 05-09-07	NO: 05-11-95	DEPT: M	QTY: 1

LET.	REDRAWN	05-09-07	M.A.
	MODIFICATION	DATE	INT.

005A0457

1005A0568

ITEM	PART #	DESCRIPTION	QT.
1	051-0256	BOLT 1/4"-20nc. X 1 3/4" CAP SKT S/S	4
2	002-0514	SEAL BAR SUPPORT	1
3	005A0152	SEAL BAR PRE-ASSY	1
4	001-1962	EXTERIOR BELLOW'S COVER	1
5	001-1963	EXTERIOR BELLOW'S COVER	1
6	001-0269	SEAL BAR GUIDE	2
7	051-0230	HEX BOLT 1/4"-20 x 1 1/4" SS	3
8	051-0740	WASHER 1/4" FLAT S/S	8
9	051-0581	NUT 1/4"-20 NYLON LOCK S/S	7
10	038-0230	WIRING DUCT W/ ADHESIVE BACKING ( 0.35" x 0.5" x 499 (1.7)	1
11	051-0250	BOLT 1/4"-20nc. X 1 1/2" S/S	4




-TWIN SEAL OPTION-

MACHINE		SIPROMAC	
PART		ST. GERMAIN DE GRANTHAM	
ITEM		CURBEC CANADA	
DATE		05-09-13	
DRAWN BY		M-1	
CHECKED BY		LISTE	
APP. BY		005A0568	


C	REDRAWN	05-09-13	M.A.
LET.	MODIFICATION	DATE	INT.

005A0152

ITEM	PART #	DESCRIPTION	QT.
1	002A0314	SEAL BAR	1
2	039-0268	DOUBLE SEAM BAND (8MM) (2.3)	1
3	176-0200	TEFLON TAPE, 5MIL (0.78)	1
4	056-1401	3/8" SET SCREW BANDING BUCKLE S/S	2
5	052-0393	SCREW 1/4-28x3/16" SKT SET OVAL POINT ZINC	2
6	051-0104	SCREW 8-32 x 3/8" RND PHIL S/S	2
7	051-0550	NUT #8-32 SS	4
8	027-0400	CONNECTOR ADAPTOR	2
9	001A2742	8mm ELEMENT BINDER	2
10	051-0146	SCREW 10-24 X 1" PAN PHIL S/S	2
11	051-0572	LOCK NUT #10-24 S/S	2
12	171-0180	TAPE CLEAR SUPER BOND 3/4" 641.5mm (0.019)	2



-DÉTAIL A-



INSTALLER CONTRE L'ENCOCHE DE L'ITEM #8 (4) INSTALL AGAINST NOTCH OF ITEM #8

VOIR DÉTAIL A

-TWIN SEAL OPTION-

550A & 600A

SEAL BAR PRE-ASSY

DESCRIPTION	550A & 600A
PART	SEAL BAR PRE-ASSY
ITEM	CNC
DATE	05-09-13
APP. BY	M.A.L.

DETAILED METRIC INCH	1.000
CONVERSION	2.54
SCALE	1:1
SCALE	1:1
SCALE	1:1
SCALE	1:1

N.T.S.

600A	4
550A	2
MACHINE	QTY
SIPROMAC	
ST. GERMAIN DE GRANTHAM	
QUEBEC CANADA	

C	ADDED 052-0393	06-04-19	M.A.
F	051-0104 & 001B2742 ETAIT 051-0100 & 009A0187	06-03-06	J.G.
E	REDRAWN	05-09-13	M.A.
LET.	MODIFICATION	DATE	INT.


M-1

LISTE

005A0152

# 1005B0569

ITEM	PART #	DESCRIPTION	QTY.
1	051-0256	BOLT 1/4"-20nc. X 1 3/4" CAP SKT S/S	4
2	002-0514	SEAL BAR SUPPORT	1
3	005B0153	SEAL BAR PRE-ASSY	1
4	001-1962	EXTERIOR BELLOWS COVER	1
5	001-1963	EXTERIOR BELLOWS COVER	1
6	001-0269	SEAL BAR GUIDE	2
7	051-0230	HEX BOLT 1/4"-20 x 1 1/4" SS	3
8	051-0740	WASHER 1/4" FLAT S/S	8
9	051-0581	NUT 1/4"-20 NYLON LOCK S/S	7
10	038-0230	WIRING DUCT W/ ADHESIVE BACKING (0.35" x 0.5" x 499 (1.7)	1
11	051-0250	BOLT 1/4"-20nc. X 1 1/2" S/S	4



500A	4
550A	2
MACHINE QTY	
SIPROMAC	
BT-GERMAIN DE GRANVILLE	
QUEBEC CANADA	

550A & 600A  
SEAL BAR ASSY W/SUPPORT

DEPT. M.I. LISTE  
DATE 06-05-29  
APP. BY


005B0569

C	REDRAWN	06-05-29	M.A.
LET.	MODIFICATION	DATE	INT.



1004A1326

ITEM	PART #	DESCRIPTION	QTY.
1	002A2061	UPPER SEAL BAR SUPPORT (E.C.O.)	1
2	008-0311	UPPER SEAL BAR RUBBER	1
3	008A0832	TEFLON CUTTING STRIP	1



— SABLER LE DESSOUS AU GRAIN 180, NETTOYER À L'ACÉTONE.  
 COLLER ITEM #3 AVEC DE LA COLLE SILICONE "SUPERFLEX" #169-0201

**NOTE:**

-INSTALLER ITEM #3 SEULEMENT SI  
 L'OPTION "SHRINKABLE BAG"  
 EST COMMANDÉE.


**-BAG CUT OPTION-**

MACHINE	600A	DEPT.	M-1	QTY.	2
PART	UPPER SEAL BAR ASSEMBLY (E.C.O.)	DATE	06-03-07	NO.	004A1326
ITEM		BY	J.G.	CHKD BY	6-6-04
MAT.					

LET.	MODIFICATION	DATE	INT.
------	--------------	------	------

1005A0573

ITEM	PART #	DESCRIPTION	QTY.
1	002A0403	UPPER SEAL BAR SUPPORT	1
2	008-0311	UPPER SEAL BAR RUBBER	1




NAME: 600A PART: UPPER SEAL BAR ASSEMBLY ITEM: _____ MAT: _____		METRIC UNIT: mm TOLERANCE: ± 0.15 DIMENSIONS: 0.05 ± 0.05 SURFACE: 0.05 ± 0.05 FINISH: N.T.S. ANGLE: ± 1°	SIPROMAC ST-GERMAIN DE GRANTHAM QUEBEC CANADA
DATE: 99-07-15	SCALE: _____	QTY: 2	NO: 005A0573
BY: S.L.	DATE: _____	BY: S.L.	DATE: _____
CHK: _____	DATE: _____	CHK: _____	DATE: _____

99-07-15	S.L.	NT.
DATE	BY	INIT.
MODIFICATION		
LET.		

005A0570

ITEM	PART #	DESCRIPTION	QT.
1	051-0256	BOLT 1/4"-20nc. X 1 3/4" CAP SKT S/S	4
2	002-0514	SEAL BAR SUPPORT	1
3	005A0370	SEAL BAR PRE-ASSY	1
4	001-1962	EXTERIOR BELLOWS COVER	1
5	001-1963	EXTERIOR BELLOWS COVER	1
6	001-0269	SEAL BAR GUIDE	2
7	051-0230	HEX BOLT 1/4-20 x 1 1/4" SS	3
8	051-0740	WASHER 1/4" FLAT S/S	8
9	051-0581	NUT 1/4"-20 NYLON LOCK S/S	7
10	038-0230	WIRING DUCT W/ ADHESIVE BACKING (0.35" x 0.5" x 499 (1.7))	1
11	051-0250	BOLT 1/4"-20nc. X 1 1/2" S/S	4



THIS SIDE OF SEAL BAR  
TO FIT FLUSH W/ SUPPORT

-TOP & BOTTOM  
SEALING OPTION-

600A	4
550A	2
MACHINE	QTY

MACHINE	550A & 600A	DEPT.	M-1	QTY	LISTE
PART	SEAL BAR ASSY W/ SUPPORT	DATE	07-12-17	DATE	07-12-17
STEM		APP. BY		DATE	07-12-17
MAX.					
USAGE 1.01 ± 0.004 TOLERANCE 1.05 ± 0.025 SURFACE 2.05 ± 0.020		N.T.S.		SIPROMAC ST-GERMANY DE GRANTHAM QUEREY, CANADA	


B	REDRAWN	07-12-17	M.A.
LET.	MODIFICATION	DATE	INT.

005A0570



005A0370

ITEM	PART #	DESCRIPTION	QT.
1	002A0314	SEAL BAR	1
2	001-2666	ELEMENT BINDER	2
3	051-0146	SCREW 10-24 X 1" PAN PHIL S/S	2
4	051-0572	LOCK NUT #10-24 S/S	2
5	051-0104	SCREW 8-32 x 3/8" RND PHIL S/S	2
6	051-0550	NUT #8-32 SS	4
7	027-0400	CONNECTOR ADAPTOR	2
8	179-0003	SILICONE 2mm x 15mm 641.5mm (0.64)	1
9	176-0220	TEFLON TAPE, PRESS SENSITIVE 2" 641.5mm (0.078)	1
10	039-0220	BI-ACTIVE SEALING ELEMENT (0.07)	1
11	056-1400	1/4"SET SCREW BANDING BUCKLE S/S	2
12	176-0200	TEFLON TAPE, 5MIL (0.78)	1
13	171-0180	TAPE CLEAR SUPER BOND 3/4" 641.5mm (0.019)	2




ALLOW TO MOVE FREELY (2) PERMETTRE DE BOUGER LIBREMENT

DETAIL B

VOIR DETAIL A

INSTALLER CONTRE L'ENCOCHE DE L'ITEM #2 (1) INSTALL AGAINST NOTCH OF ITEM #2




-DETAIL A-

-TOP & BOTTOM  
SEALING OPTION-

MACHINE	600A	4
	550A	2
MACHINE	QTY	
	SIPROMAC	
	ST-GERMAIN DE GRANBRIAN	
	CHIBOUQUE, CANADA	
DEPT. EX. INCL. IN USE	1.5	1.5
USURANCE	1.5	1.5
TOLERANCE	1.5	1.5
SCODAGE	1.5	1.5
	N.T.S.	
ITEM	PRE-ASSY	
DATE	07-12-17	
REVISION	M.A.	
LISTE	M-1	
NO.	005A0370	



E	REDRAWN	07-12-17	M.A.
LET.	MODIFICATION		DATE / INT.

005A0386



CE COTÉ DE LA BARRE DOIT ÊTRE ÉGAL  
AU SUPPORT  
THIS SIDE OF SEAL BAR TO FIT FLUSH  
WITH SUPPORT

ITEM	PART #	DESCRIPTION	QT.
1	002A0534	UPPER SEAL BAR SUPPORT	1
2	002A0349	UPPER SEAL BAR	1
3	051-0220	SCREW 1/4" x 1" SKT. CAP S/S	8
4	001-2666	ELEMENT BINDER	2
5	051-0146	SCREW 10-24 X 1" PAN PHIL S/S	2
6	051-0572	LOCK NUT #10-24 S/S	2
7	051-0104	SCREW 8-32 x 3/8" RND PHIL S/S	2
8	051-0550	NUT #8-32 SS	4
9	027-0400	CONNECTOR ADAPTOR	2
10	179-0003	SILICONE 2mm x 15mm ADHESIVE 683mm (0.68)	1
11	176-0220	TEFLON TAPE, PRESS.SENSITIVE 2" 683mm (0.08)	2
12	039-0220	BI-ACTIVE SEALING ELEMENT (6mm) 726mm (0.07)	1
13	056-1400	1/4" SET SCREW BANDING BUCKLE S/S	2
14	171-0180	TAPE CLEAR SUPER BOND 3/4" 650mm (0.020)	2



DETAIL A

**-TOP & BOTTOM SEALING OPTION-**




MACHINE	600A	DEPT.	M-1	QTY.	2
PART	UPPER SEAL BAR ASSY WSUPPORT	STATION	ST-GEMAR DE GRANBY QUEBEC CANADA	DATE	07-12-17
ITEM		REV.	J.G.	DATE	07-12-17
NAT.		DESIGNED BY	J.G.	DATE	07-12-17
		REVISION	REDESSINE	DATE	07-12-17
		MODIFICATION	MODIFICATION	DATE	INT.
				NO.	005A0386

F. J.G. 07-12-17  
L.E.T. DATE INT.












# ELECTRICAL DRAWING







006-0068

\* RC SUPPRESSOR ADD ON EACH COIL



OPTION	VOLTAGE	FUSE F2	FUSE F5	MOTOR (HP)	PUMP
TWIN SEAL & BAG CUT	220	034-0430	034-0200	3	FUSE F1 230-1
TWIN SEAL & BAG CUT	380	034-0430	034-0410	3	230-3
TWIN SEAL & BAG CUT	600	034-0425	034-0410	3	034-0530
TOP & BOTTOM SEAL	220	034-0500	034-0200	3	034-0460
TOP & BOTTOM SEAL	380	034-0485	034-0410	5	230-1
TOP & BOTTOM SEAL	600	034-0440	034-0410	5	230-3
				5	575-3



COLOR CODE PRIMARY (VAC)

WHITE	0V
BLACK	190V
GREY	208V
RED	230V
BROWN	380V
YELLOW	460-480V
BLUE	575-600V
SECONDARY (VAC)	
RED	24V
PURPLE	9V

MACHINE

420A, 600A & 620A

PIECE

ELECT. WIRING HIGH VOLTAGE 1ø

Q1:

ECH. SCALE

NE PAS MESURER / N.T.S.

MAT:

DESS. D. LETOURNEAU

DATE 97-03-10

IND.

DATE

SIPROMAC

ST-GERMAN DE GRANTHAM  
QUEBEC CANADA

006-0068







1006-0069

PUMP		
MOTOR (HP)	VOLT +ph	FUSE F1
3	230-1	034-0660
3	230-3	034-0530
3	575-3	034-0480
5	230-1	034-0570
5	230-3	034-0550
5	575-3	034-0610

OPTION	VOLTAGE	FUSE F2	FUSE F5
TWIN SEAL	220	034-0450	034-0200
TWIN SEAL	380	034-0430	034-0410
TWIN SEAL	600	034-0425	034-0410
TOP & BOTTOM SEAL	220	034-0500	034-0200
TOP & BOTTOM SEAL	380	034-0485	034-0410
TOP & BOTTOM SEAL	600	034-0440	034-0410

WIRE GAGE  
 W1: TEW #10  
 W2: TEW #12



\*RC SUPPRESSOR ADD ON EACH COIL

MACHINE 420A, 600A & 620A

PIECE ELECT. WIRING HIGH VOLTAGE 3Ø

GT. \_\_\_\_\_ ECH. SCALE \_\_\_\_\_

MAT. \_\_\_\_\_

DESS. D. LETOURBEAU DATE 87-03-10

APP. \_\_\_\_\_



NO. 006-0069

SIPROMAC  
 ST-GERMAIN DE GRANTHAM,  
 QUEBEC CANADA

- COLOR CODE PRIMARY (VAC)
- WHITE 0V
  - BLACK 190V
  - GREY 208V
  - RED 230V
  - BROWN 380V
  - YELLOW 460-480V
  - BLUE 575-600V
- SECONDARY (VAC)
- RED 24V
  - PURPLE 9V

1006-0101

OPTION	VOLTAGE	FUSE F2	FUSE F5	MOTOR (HP)	PUMP	FUSE F1
TWIN SEAL & BAG CUT	220	034-0450	034-0200	3	230-1	034-0550
TWIN SEAL & BAG CUT	380	034-0430	034-0410	3	230-3	034-0530
TWIN SEAL & BAG CUT	600	034-0425	034-0410	3	575-3	034-0480
TOP & BOTTOM SEAL	220	034-0500	034-0200	5	230-1	034-0570
TOP & BOTTOM SEAL	380	034-0465	034-0410	5	230-3	034-0550
TOP & BOTTOM SEAL	600	034-0440	034-0410	5	575-3	034-0610



COLOR CODE PRIMARY(VAC)

WHITE	0V
BLACK	190V
GREY	208V
RED	230V
BROWN	380V
YELLOW	460-480V
BLUE	575-600V

SECONDARY(VAC)

RED	24V
PURPLE	9V

MACHINE 420A, 600A & 620A

PIECE ELECT. WIRING HIGH VOLTAGE 10.50 HZ

GT. ECH. SCALE

NE PAS MESURER / N.T.S.

DESS. DATE 97-03-11

D. L'ETOURNEAU DATE

APP. NO. 006-0101

ST-GERMAIN DE GRANTHAM, QUEBEC CANADA

SIPROMAC

\* USE ONLY "STARS WASHERS" FOR TRANSFO. FIXATION.

\* CONTROL TRANSFO. 24V 9V

\* SEALING TRANSFO. X1 X2

H1 H2

61 52

77 76 75


74 78

006-0102


OPTION	VOLTAGE	FUSE F2	FUSE F5
TWIN SEAL	220	034-0450	034-0200
TWIN SEAL	380	034-0430	034-0410
TWIN SEAL	600	034-0425	034-0410
TOP & BOTTOM SEAL	220	034-0500	034-0200
TOP & BOTTOM SEAL	380	034-0465	034-0410
TOP & BOTTOM SEAL	600	034-0440	034-0410

MOTOR (HP)	VOL.T. +rpm	FUSE F1
3	230-1	034-0550
3	230-3	034-0530
3	575-3	034-0480
5	230-1	034-0570
5	230-3	034-0550
5	575-3	034-0510

\* RC SUPPRESSOR ADD ON EACH COIL



- \* NO
- \* NC
- \* COM



- COLOR CODE PRIMARY (VAC)
- 0V WHITE
  - 190V BLACK
  - 208V GREY
  - 230V RED
  - 380V BROWN
  - 460-480V YELLOW
  - 575-600V BLUE
- SECONDARY (VAC)
- 24V RED
  - 9V PURPLE

\* USE STARS WASHERS FOR TRANSFO. FIXATION.

420A, 600A & 620A

ELECT. WIRING HIGH VOLTAGE (50 HZ) 3P

NE PAS MESURER / N.T.S.

SIPROMAC


ST-GERMAIN DE GRANTHAM, QUEBEC CANADA

DATE 05-10-02



APP. \_\_\_\_\_

NO. 006-0102


SINGLE CHAMBER



DOUBLE CHAMBER



SEALING BAR



SEALING BAR

① WIRE TEW 12 AWG SIPROMAC # 030-0420

② WIRE CABTIRE 12/3 SJ SIPROMAC # 030-0120  
CONNECTOR CD-13 SIPROMAC # 036-0409

MACHINE

ALL MODEL

PIECE

WIRING FOR SEALING BAR

QT.

ECH. SCALE

NE PAS MESURER / N.T.S.

MAT.

DES. ERIC J. I.P.  
APP.

DATE 12 DEC 2000

NO.

006-0131


SIPROMAC

ST-GERMAIN DE GRANTHAM,  
QUEBEC CANADA



## ELECTRICAL DRAWINGS PARTS LIST

A :	VOLT	PHASE	PUMP HP	CONTACTOR	OVERLOAD
220		1	3	025-0040	025-0190
220		3	3	025-0020	025-0180
575		3	3	025-0010	025-0150
220		1	4	025-0050	025-0200
220		3	4	025-0030	025-0190
460		3	4	025-0010	025-0170
575		3	4	025-0010	025-0160
220		1	7.5	025-0070	025-0222
220		3	7.5	025-0040	025-0210
575		3	7.5	025-0010	025-0180

B,C & O:	SEALING CONTACTOR:	025-0020
D:	OPTIONAL GAZ SOLENOID VALVE:	106-0010
E:	VACUUM SOLENOID VALVE:	106-0050
F:	ATMOSPHERE SOLENOID VALVE:	106-0030 WITH PUMPS: 3HP & 4HP 106-0050 WITH PUMP: 7.5 HP
G:	BELLOWS SOLENOID VALVE:	106-0070
H, I, J:	COVER SWITCH:	026-0590
K:	SEALING TRANSFO.:	
	TWIN SEAL & BAG CUT:	029-0040, 029-0050
	TOP & BOTTOM SEALING:	029-0080
L:	RELAY & BASE:	
	RELAY:	025-0600
	BASE:	025-0610
M:	OPTIONAL TOP SEALING CONTACTOR:	025-0020
N:	CONTROL TRANSFO.:	029-0007, 029-0008, 029-0009, 029-0250




# PNEUMATIC DRAWING




007-0019

ITEM	PART #	DESCRIPTION	QTY.
1	106-0010	GAS VALVE	2*
2	114-0260	VACUUM GAUGE	1
3A	106-0070	BELLOWS VALVE	1
3B	106-0070	BELLOWS VALVE	1*
4	114-0147	PRESSURE REGULATOR	1*
5	114-0245	PRESSURE GAUGE	1*
6	114-0170	PRESSURE REGULATOR SUPPORT	1*
7	106-0030	ATMOSPHERE VALVE FOR 420A	1
	106-0030	ATMOSPHERE VALVE FOR 600A, 63M <sup>3</sup> AND 100 M <sup>3</sup>	
	106-0050	ATMOSPHERE VALVE FOR 600A & 620A; 160 M <sup>3</sup> AND 250 M <sup>3</sup>	
8	106-0050	ATMOSPHERE VALVE FOR 650A & 700A	1
	106-0030	VACUUM VALVE FOR 420A	
	106-0050	VACUUM VALVE FOR 600A & 620A	
	106-0060	VACUUM VALVE FOR 650A & 700A	

\*: OPTION




-NOTE:  
-FOR GAS INJECTION  
KIT INSTALLATION  
SEE DRAWINGS #:  
420A: #010-0016  
600A: #010-0017  
620A: #010-0018  
650A: #010-0020



NOTE: SET TO A  
MAXIMUM OF 45 PSI

-NOTE:  
-FOR AIR REGULATOR  
OPTION KIT INSTALLATION  
SEE DRAWINGS # 010-0019  
& 650A: #010-0027  
(FOR EXISTING MACHINES)



WITH OPTIONS

WITHOUT OPTION

MACHINE <b>420A, 600A, 620A &amp; 650A</b>		PART <b>PNEUMATIC</b>		SIPROMAC ST-GERMAIN DE GRANTHAM QUEBEC CANADA	
ITEM: _____ ENG: _____ DATE: 97-03-11	DATE: 97-03-11	N.T.S.	SCALE: _____	QTY: 1	NO. 007-0019
RE-DRAWN LET. _____		MODIFICATION DATE: _____		DATE: 97-03-11	



May 14, 1992

Sipromac, Inc.

The following equipment is acceptable for use in federally inspected meat and poultry plants:

EQUIPMENT: Vacuum Packaging Machine, Models: Sipromac 650A, Sipromac 600A, Sipromac 550A, and Sipromac 420A

This acceptance is with the understanding that all future equipment designated by a similar model number will be of the same design and material as those for which this letter is written. Once this equipment is published in our "Accepted Meat and Poultry Equipment" booklet, this letter becomes invalid and can no longer be used as an authorization for installation of equipment in plants.

This acceptance does not imply compliance with Department of Labor Occupational Safety and Health Standards, nor should it be considered as an approval of processing methods. Any departure from established procedures must be cleared with the Slaughter Inspection Standards and Procedures Division or the Processed Products Inspection Division.

Sincerely,

Robert E. Owens  
Industrial Specialist  
Equipment Branch  
Facilities, Equipment and Sanitation Division  
Science and Technology


PECU






# NOTES







450A




400A




450T




380A




350/350D




300




250




600A



420A




580A




550A


VACUUM PACKAGING MACHINES




750A




700A




680A



650A



620A



# MANUEL D'UTILISATEUR

## MICROPROCESSUR MC-40 AVEC DÉTECTEUR DE VIDE

### EMBALLEUSE SOUS VIDE

### TABLE DES MATIÈRES

#### I INSTRUCTIONS POUR LES OPÉRATIONS

#### II MÉCANIQUE

- A- Vue de face
- B- Vue de l'arrière
- C- Procédure d'ajustement du couvert
- D- Schéma de l'assemblage de l'axe central
- E- Barres de scellage  
(Double scellage)
- F- Dessin des barres de scellage  
(Option du coupe sac électrique)
- G- Dessins des barres d'assemblage  
(Scellage du haut et du bas en option)
- H- Gas injection kit installation drawing  
(gaz injection option)

#### III ELECTRIQUE

- A- Schéma électrique (Bas voltage)
- B- Schéma électrique (Haut voltage à une phase)
- C- Schéma électrique (Haut voltage à 3 phases)
- D- Schéma électrique (Haut voltage 1 phase 50 Hz)
- E- Schéma électrique (Haut voltage 3 phase 50 Hz)

#### IV PNEUMATIQUE

- A- Schéma Pneumatique

# EMBALLEUSES SOUS VIDE INSTRUCTIONS D'OPÉRATIONS

## TABLE DES MATIÈRES

1. Mise en marche de la machine
2. Connexion Électrique
3. Opération
  - 3.1 Principes de travail
  - 3.2 Emballage Spécial
    - 3.2.1 Injection de Gaz
    - 3.2.2 Scellage haut et bas  
(bi-active sealing)
    - 3.2.3 Coupe sac électrique
  - 3.3 Ajustement des contrôles digital
  - 3.4 Nettoyage Quotidien
4. Trouble de lancement
  - 4.1 Échec durant le cycle d'emballage
  - 4.2 Vide insuffisant
    - 4.2.1 Fuites dans le sac
    - 4.2.2 Pas de fuite dans le sac
    - 4.2.3 Vide insuffisant dans la chambre
  - 4.3 Scellage Inadéquat
    - 4.3.1 Scellage insuffisant
    - 4.3.2 Pas de scellage
    - 4.3.3 Courant ininterrompu sur les barres de scellage
    - 4.3.4 Le scellage ne tient pas
  - 4.4 Problème avec les valves
  - 4.5 Problème du panneau de contrôle
5. Maintenance Régulière

# SIPROMAC INC. EMBALLEUSES SOUS VIDE

## 1. MISE EN PLACE DE LA MACHINE:

Avant de choisir le site d'installation de votre machine, veuillez considérer que vous aurez besoin d'espace pour les produits emballés et non-emballés à part de l'espace occupé par la machine elle-même.

Bien vouloir vous rappelez que vous aurez besoin d'un sol bien au niveau pour votre installation. Spécialement avec les modèles mobiles, le poids de la pompe peut gauchir la machine et le couvercle ne fermera plus correctement.

Avant de commencer à travailler, vérifier l'huile de la pompe pour voir si elle est en quantité suffisante. Bien vouloir ne jamais utiliser une huile autre que celle recommandée par le fabricant. Ne pas excéder la quantité indiquée quand vous ajoutez ou faites le changement d'huile et faites votre vérification hebdomadairement.

En raison de la viscosité de l'huile, la machine sera plus difficile à démarrer à basses températures. Ainsi donc la pompe doit être placée dans un endroit où la température est d'au moins 50°F (+10°C). D'autre part, l'air doit circuler librement aux alentours de la pompe pour permettre le refroidissement dans les cas où la température des opérations atteindrait 160°F (70°C) ou la température maximale permise.

## 2. CONNEXION ÉLECTRIQUE:

Les connexions électriques doivent se faire par du personnel qualifié. La personne désignée doit s'assurer que les entrées électriques correspondent au voltage et à l'ampérage approprié de la machine.

Un schéma électrique accompagne chacune de nos machines.

Une étape importante dans le branchement de la machine est de s'assurer que le moteur de la pompe tourne dans une rotation appropriée.

Attention: Le moteur de la pompe ne devrait pas tourner plus de 3 ou 4 secondes dans une mauvaise rotation car il en résultera des dommages sérieux. La rotation est indiquée par une flèche sur le moteur de la pompe.

## 3. OPÉRATION:


### 3.1 Principes de travail:

Un emballage sous vide est un cycle composé de 3 étapes. Premièrement le vide est fait et l'air est complètement enlevé de la chambre et du sac contenant le produit. (Voir figure 1). Ensuite c'est possible d'injecter du gaz neutre par les conduits si le produit est très délicat. Finalement, un mécanisme pousse la barre de scellage sur le support de caoutchouc pour sceller le sac



Pour obtenir de beaux emballages, les produits et les sacs doivent être de taille proportionnelles. L'ouverture du sac ne devrait jamais excéder 2" (50cm) au delà des barres de scellage. Le produit doit être centré en hauteur par rapport aux barres de scellage en ajustant les écarteurs qui vous sont fournis.

Pour obtenir un bon scellage, assurez-vous qu'il n'y a pas de résidu de graisse qui reste entre les côtés intérieurs des sacs où le scellage doit être fait.



### 3.2 Emballage Spécial:

#### 3.2.1 Injection de Gaz (option):

Il y a une pression atmosphérique de 14 lbs / pouce carré (= 1 kg / cm carré) sur les produits quand le vide demandé est atteint. Les produits qui peuvent être endommagés par une haute pression doivent être emballés avec un vide partiel et la pression doit être contrebalancée en injectant du gaz dans le sac (nitrogène ou dioxyde de carbone) avant le scellement et après avoir atteint le vide.

Pour l'injection de gaz, les sacs sont placés sur les barres de scellage, l'ouverture placée au dessus des conduits de gaz qui sont montés le long des barres de scellage. Après que le vide soit atteint, la valve du vide se ferme et la valve du gaz s'ouvre. Le pourcentage de gaz peut être ajusté par le menu du programme.

Le réservoir de gaz et la valve de pression qui est rattachée au réservoir ne sont pas fournis par Sipromac. La pression pour le régulateur de gaz devrait être ajustée approximativement à 5 lbs/pouce carré (1/3 Kg/cm carré). Chaque machine a un adaptateur pour la connexion de gaz quand l'option de l'injection de gaz est commandée.

#### 3.2.2 Scellage Haut et Bas (optionnel):

Pour le scellage des sacs en aluminium comme pour le café il est impératif d'avoir une barre de scellage en haut et en bas.

#### 3.2.3 Coupe sac électrique: (optionnel):

Cette option est utilisée pour obtenir un paquet dont l'excédent de film au niveau du scellage doit être coupée très près de la ligne de scellage. ( cette option ne peut pas être utilisée avec le scellage Haut et Bas)

### 3.3 Les opérations de l'emballage sous vide:

Note: Reportez-vous aux menus structure de la page 8 et aux détails du panneau de contrôle sur la page 9

#### 3.3.1 Bases:

Utilisez la touche "POWER" pour initier le bouton ON/OFF sur votre machine sous vide. Quand votre unité sera en fonction le dernier programme exécuté apparaîtra sur l'écran à cristaux liquides.

Utilisez la touche "ESC" pour passer du menu programme au menu fonctions et du menu des fonctions au menu des programmes.

Dans le menu des fonctions, utilisez la touche "SELECT" pour sélectionner une fonction et la touche "ENTER" pour exécuter la sélection.

Dans le menu des programmes, utilisez la touche "SELECT" pour sélectionner un programme et la touche "Enter" pour accéder ou modifier la sélection.

Dans les programmes du sous menu, utilisez la touche "ENTER" pour voir défiler les paramètres et lorsque ces derniers clignotent pour indiquer ils sont dans le mode d'acquisition. Quand la séquence de tous les paramètres se sont affichés, on revient automatiquement au début de la liste.

Dans les programmes du sous menu, utilisez la touche "ESC" pour revenir au menu des programmes. Pressez n'importe quelle touche pour effacer les messages d'erreur qui peuvent s'afficher sur l'écran à cristaux liquide.

#### 3.3.2 Menu des fonctions:

##### 3.3.2.1 Créer un programme:

Quand vous exécutez la fonction "create a program", le programme sous menu est atteint en commençant par l'identification. L'identification initiale "PxxNO NAME" est donné au programme et tous les paramètres sont établis à zéro; le numéro du programme est alloué automatiquement.

##### 3.3.2.2 Supprimer un programme:

En exécutant la fonction de "delete a program", vous avez accès au menu des programmes et le numéro du premier programme en mémoire clignote pour indiquer le mode de suppression. Utilisez la touche "SELECT" pour sélectionner un programme et la touche "ENTER" pour avoir accès et confirmer la suppression de la sélection. Utilisez la touche "ESC" pour annuler une suppression et quitter la fonction. Quand vous quittez la fonction, le nombre des programmes actuels sur l'écran à cristaux liquides cesse de clignoter.

##### 3.3.2.3 Choisir le mode d'opération:

Quand vous exécutez la fonction "Select Operating Mode", laquelle est disponible seulement pour les unités automatiques, la sélection en cours clignote pour vous indiquez le mode. Utilisez la touche "SELECT" pour parcourir les modes d'opération, lesquels sont automatiques, semi-automatiques et manuels. Le mode

d'opération sera validé et exécuté automatiquement. Utilisez la touche "ESC" ou "ENTER" pour quitter la fonction et retourner au menu des programmes.

### 3.3.3 Menu des Programmes:

#### 3.3.3.1 Identification des Programmes:

Pour un programme sélectionné, choisissez l'identification en utilisant le panneau de contrôle numérique avec la chartre des caractères et pressez sur la touche numérique jusqu'à ce que le caractère soit sélectionné (4 x pour la valeur numérique). Utilisez la touche "ENTER" pour valider le caractère ainsi que la chaîne de caractères jusqu'à la fin ( la nouvelle chaîne de caractères clignote). Vous pouvez utiliser la touche "ESC" pour revenir en arrière dans le cas où vous vous êtes trompé et que vous voulez effacer le caractère.

Exemple: EXAMPLE 1 → Touche 2, 2, ENTER → E  
(9 caractères) Touche 8, 8, 8, ENTER → X  
Touche 1, ENTER → A  
Touche 5, ENTER → M  
Touche 6, ENTER → P  
Touche 4, 4, 4, ENTER → L  
Touche 2, 2, ENTER → E  
Touche 9, 9, 9, ENTER → espace  
Touche 1, 1, 1, 1, ENTER → 1  
Touche ENTER pour valider la chaîne de caractères

#### 3.3.3.2 L'ajustement du niveau de Vide:

Pour un programme sélectionné, ajustez le niveau de vide avec les valeurs; le point décimal est automatiquement inséré suivant la deuxième entrée digitale et la validation est automatiquement exécutée après la troisième entrée digitale ( La nouvelle valeur du niveau du vide clignote). Le niveau de vide est arrondi à la demie la plus près de la valeur. En cours de traitement, utilisez la touche "ENTER" pour valider la valeur du niveau de vide et la touche "ESC" pour revenir en arrière et changer la valeur du niveau de vide ( La valeur du niveau de vide la plus ancienne clignotera à ce moment). Ajustez le niveau du vide à zéro pour pouvoir contourner le capteur de vide et procédez en réglant seulement le " Temps de vide Plus" (Vacuum plus time).

Exemples: 90.0% → Touches 9, 0, 0 ou 9, 0, ENTER ou  
Touches 9, 0, 1 ou 9, 0, 2 or 9, 0, 3 ou 9, 0, 4  
97.5% → Touches 9, 7, 5 ou  
Touches 9, 7, 6 ou 9, 0, 7 or 9, 0, 8 ou 9, 0, 9  
0.0% → Touches 0, 0, 0 ou 0, ENTER

#### 3.3.3.3 Ajustement du Temps de Vide "Plus":

Pour un programme sélectionné, réglez le "temps de vide plus" en secondes; la validation est automatiquement exécutée après la deuxième entrée digitale ( La nouvelle valeur du "temps de vide plus" clignotera à ce moment). En cours de traitement, utilisez la touche "ENTER" pour valider la nouvelle valeur du "temps de vide plus" et la touche "ESC" pour revenir et recommencer avec de nouvelles



"ENTER" afin d'accéder et modifier le programme; les paramètres deviennent valides seulement pour les cycles suivants de vide.

### 3.3.5 System monitor:

Pour accéder le menu des diagnostics, monter la puissance de la machine d'emballage sous vide tout en maintenant le bouton "ESC" enfoncé. Utilisez la clé "SELECT" pour choisir la fonction du système du moniteur et "ENTER" pour accéder et visualiser les paramètres surveillés. Employez la clé "SELECT" pour changer la révision de logiciel, la quantité d'heures de travail faites et de la quantité de cycles complets exécutés depuis la première initialisation.

## -MENUS STRUCTURE-

- Functions menu:

"F1 CREATE A PRGM"  
"F2 DELETE A PRGM"  
"F3 SELECT OPMODE" (automatic units only)

- Programs menu:

"Pxx NAME"

Program submenu:

	"VACUUM: xx.x%"	(10.0% - 99.5%)
	"VACUUM PLUS: xxs"	(0s - 99s)
(units with gas option)	"GAS FLUSH: xx.x%"	(0.0% - 10% below the vacuum level)
	"SEAL TIME: x.xxs"	(0.00s - maximum unit allocated setting)
	"Pxx NAME"	(12 characters)

- Diagnostics menu (keys "ESC" & "POWER" for access):

"DIAGNOSTICS MENU" (access code required)

"D1 INPUTS TEST"

"D2 OUTPUTS TEST"

"D3 MODEL SELECT"

"D4 GAS OPTION"

"D5 SEALING TIME"

"D6 COOLING TIME"

"D7 LOADING TIME" (automatic units only)

"D8 UNLOADNG TIME" (automatic units only)

"SYSTEM MONITOR" (no access code required)


"SOFTWARE: R x.xx"

"WORK HRS: xxxxx"


"CYCLES: xxxxxxx"

# PROGRAMMATION MC-40


## Pour modifier un programme déjà créé



## Pour créer un programme




## Pour sélectionner un programme créé



## SYSTEM MONITOR


Pour accéder au menu "system monitor", mettre la machine à off, tenir la touche "esc", appuyer et relacher la touche "on/off" et finalement relacher la touche "esc". L'affichage indique DIAGNOSTIC MENU, appuyer sur select pour accéder au SYSTEM MONITOR.






# DIAGNOSTIC MENU

Pour accéder au "DIAGNOSTIC MENU", mettre la machine à off, tenir la touche "esc", appuyer et relacher la touche "on/off" et finalement relacher la touche "esc". L'affichage indique DIAGNOSTIC MENU, appuyer sur enter pour y accéder.





Drag the side handles to change the width of the text block.

Entrer le temps de scellage maximum